540.00mm

120.00mm

正反印刷
风琴五折

DUTZO

CPU LIQUID COOLER
KORI ARGB 240/360

QUICK INSTALL GUIDE

▶▶▶ BRACKET COMPONENTS

x1 **A**
x1 **B**
x2 **C** INTEL
x1 **D**
x2 **E** AMD
x4 **F**
x4 **G**
x4 **H**

▶▶▶ BRACKET COMPONENTS

x8 **I**
x4 **J**
x4 **K**
x8 for 240 / 280 AIO
x12 for 360 AIO
L
x4 **M**
x8 for 240 / 280 AIO
x12 for 360 AIO
N

1.Radiator installation

L

N

2-1.Pump bracket installation（Intel）

C
I
Intel

LGA2066/2011/1366
LGA115X
LGA775
C

2-2.Pump bracket installation（AMD）

E
I
AMD

AM2/AM2+/AM3/FM1
AM4
E

3.Apply thermal silicone grease

D

4-1.Intel LGA775/1366/115X/1200 installation

F
C
J
K
I
A
G

4-2.Intel LGA2066/2011 installation

F
C
J
J
M

5.AMD AM4/AM3/FM2 installation

E
F
C
J
K
I
B
G

6. Pump and fan power connections

CPU_FAN

CHA_FAN

7.Pump and fan RGB connection

MOTHERBOARD RGB PORT
MB SYNC CABLE
POWER
CONTROLLER WITH SELF-LOCKING CONNECTOR

MODE
SPEED
LIGHT

ARGB control unit:
Mode : Cycle between 18 lightning modes such as rainbow, spectrum, glow, monochrome, static, pulsating and flashing.

SPEED : Adjust the light effect speed. Only works for some effects. By holding the SPEED key for 4 seconds it will turn off the lightning effect.

LIGHT : Cycle between colors.

Note : SPEED key, long press for 4 seconds to turn off/ on the lighting effect.